

1. Attention of automatic car

Defend the following matter about the automatic car.

In the worst case, it reaches an unexpected accident and serious injury if it doesn't guard or, it is likely to lead to the death.


滴 Characteristic of automatic car

- Creep phenomenon

When engining starts, the gear-shift

:. 線・懸It is, and is ..power...


The phenomenon that begins to move slowly even if entering the state of, and not stepping on the gas pedal is called a creep phenomenon.



- Down of kick

It can be rapidly accelerated by engine revolutions' automatically changing into a low-speed gear if the gas pedal is fully depressed while running, and rising. This is called a down of the kick.


滴 It is not necessary to make a mistake in stepping confirming the position of the brake pedal and the gas pedal without fail when you drive.



- The car starts rapidly when the gas pedal is mistaken for the brake pedal and it steps, it causes an unexpected accident, and it reaches important injury or, in the worst case, it is likely to lead to the death. -


When retreating, it becomes difficult to operate the pedal because it becomes posture in which the body is twisted. Note that it can ensure the pedal operation. -

Can take be correct driving posture when move the car a little, and step on the brake pedal and the gas pedal surely.





澆 Operate the brake pedal by the same right leg as the gas pedal.



- The brake operation by the left leg might cause an unexpected accident as the reaction in the emergency is delayed and is dangerous.

潺 Starting up an engine must start up an engine with stepping on the brake pedal firmly.

- As for the gear-shift, the wheel is fixed because of safety. 緘 It puts, and the brake pedal is ..paving... The debt stepping engine must start.

潛 Operate the gear-shift when you start with stepping on the brake pedal firmly.

- Especially, step on more unflinching and the brake pedal so that the creep phenomenon may strengthen when immediately after the engine start and the air conditioner operates. -

Do not do the lever operation with the gas pedal absolutely depressed. It starts rapidly by the car, might cause an unexpected accident, and is dangerous.



Warning

1.

Attention

of

automatic

car



Warning

1.


Attention

of

automatic

car

澁The gear-shift while running 懸に
Do not put it.



- 懸It might cause an unexpected accident because neither nor the engine brake work completely and is dangerous. -
- 懸The lubrication of oil in an automatic transmission worsens when running at Chou time, and it is likely to break down.

澀The gear-shift while running 線Do not put.

- It is mechanically locked the inside of an automatic transmission, might cause an unexpected accident, and is dangerous.

澀The gear-shift while running to advance 緘Do not put.

- It locks by the wheel, might cause an unexpected accident, and is dangerous. Moreover, impossible power joins an automatic transmission, and it is likely to break down.

澀Do not rev while
stopping.



- 線・ 懸It is, and the car starts rapidly, and it might cause an unexpected accident and is dangerous.



潜 The gear-shift when parking 緘 P u t .

- 緘 When things except do the car in the creep phenomenon in case of being, it begins to move automatically or the gas pedal is depressed by mistake, it starts rapidly, and it might cause an unexpected accident and is dangerous.

潭 The gear-shift in 1.8L car (FF car) on the slope etc. 綺・絲.

In 1.8L car (4WD car) 綺・筋・笹・網. 2.0L(G grade)

Then, 綺・絲. Silk grade, In 2.0L car (Z grade) 綺・絢..putting...

Neither reeling nor never retreat with.

- To similar 緘 Never advance by inertia with put. It stalls, it might cause a breakdown and an unexpected accident by the steering wheel's working of the brake worsening, and becoming heavy, and it is dangerous.

澁 In addition, note the following points.

- The gear-shift : after it retreats a little. 緘 F o r g e t t i n g
It is. Soon after it retreats 縣 Can the custom of.
- The gear-shift in the counterattack etc. 綺から 緘、 緘から 綺 The lever is operated many times. Nipponia nippon must go after it pulls up a car completely of stepping on the brake pedal firmly in every case. Moreover, confirm it without forgetting the position of the gear-shift.



Warning

1.

Attention

of

automatic

car



2. Attention of 4WD car

Defend the following matter about 4WD car.

In the worst case, it reaches an unexpected accident and serious injury if it doesn't guard or, it is likely to lead to the death.



2. 4

Attention of W D car

滴 An impossible driving is a taboo.



- 4WD of this car (active torque control 4WD) is only for the on-road. Be not, and do not drive putting for running in the off-road and the rally running, etc. because 4WD of securing roadholding in a general road ..impossibility...

涵 Run carefully on a slippery road.



- No versatile car even if it is called 4WD car. Do carefully as well as a general car, and always bear the safe driving in mind about the operation of the accelerator, the steering wheel, and the brake.




Warning

2.
4

Attention

of
W
D
car

濡 It must not run idle excessively by the escape circle etc. when either of wheel is pending.



- Impossible power in driving parts when a rotation difference of the rear wheel and a violent state continue joins and receives the damage such as burning, and it might cause an unexpected accident and is dangerous dashing out of the vehicle suddenly by burning.

濡 Do not run underwater about the cross a river etc.



- It might cause a serious vehicle breakdown to damage the engine by not only the engine stall if the underwater running of the cross a river etc. is done but also the inhalation of the short of electrical equipment and water. -

Check the following item etc. in the Toyota shop when soaked in water by any chance.

蘆 Effective condition of brake.

蘆 Change in amount of oil and quality such as engine transmission transfer Def. (Because water mixes when becoming cloudy, the exchange of oil is necessary.)

蘆 Lubrication is defective in the propeller shaft, each bear, and collaborate each.




Warning

2.
4

Attention

of
W
D
car

潜 Install all of same kinds of tires in the tire by a specified size.



- Install all tires of the same size, the same manufacturer, the same brand, and the same tread pattern (ditch pattern) in the tire by a specified size. Moreover, do not install the tire with a remarkable wear-out difference mixing it. -
- It might connect with a vehicle fire in the worst case by oil leaking and burning by the temperature of oil generating an always abnormal rotation difference by the tire in the front, back, left and right if the tire is existing together used, applying impossible power to the drive and the system parts (differential gear), and rising and is dangerous.
- The drive and the system parts are negatively affected in the following cases as well as the coexistence use for the tire, and execute the check of the air pressure in the tires.
 - 蘆 When the difference of the air pressure of four wheels is remarkable.
 - 蘆 When the air pressure shifts from a specified value. -
- Rotate the tire around the wear-out of the tire to keep even, and to extend longevity to four wheels. (Refer to P.409.)-
- Do not install the disc wheels other than specification when you exchange the disc wheels. (Refer to P.453.)